

# RECREATIONAL VEHICLES



OEM



## ALKO/KOBER TRAILER AXLE

—	4600, 5000 & 7000 lb. Axles	05200300 19176 19188	555001 555001 555025	555001 555001 555025
---	-----------------------------	----------------------------	----------------------------	----------------------------

## BLUEBIRD BUS — Motorhome (Class A)

—	WanderLodge Front Front w/ Ridewell Air Suspension Drive Axle  Tag Axle	901968SP1 1750785 1750793  1722214	65430 65430 —  —	— — 65474 74438 65421
---	--	--	------------------------------	-----------------------------------

## CHEVROLET — Motorhome Chassis For Class A

1999-95	P12 (P12) Motorhome Chassis	—	65443	65414
1999-92	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109014	U0109014	—	555043
1999-73	P30 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension	—	557003	557004
1999-73	P30 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P30 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U01094	U0109004	—	34792
1985	P30 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1972-68	P30 (P32) Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
1972-68	P30 (P32) Motorhome Chassis w/ 157 in. W.B.	—	34817	—

## CHEVROLET — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P30 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913 <sup>34</sup>	—
1999-75	P30 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944	—

## CHEVROLET — Motorhome Chassis For Class B (Recreational Van Conversion)

2005-96	3500 Series Front Rear w/ Dual Wheels Load Assist Unit w/ Dual Rear Wheel Rear w/ Single Wheel Load Assist Unit w/ Single Rear Wheel	— — — — —	34741 — — — —	— 34756 555009 34763 58612**
1995-92	G-30 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-30 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-30 Series — Exc. Chopped Van	—	555035	34803

## CHEVROLET — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-30 Series w/o O.E. Steering Stabilizer	SC2915 <sup>33,34</sup>	SA1932

## CHEVROLET — Motorhome Chassis For Class C

2005-96	3500 Series Load Assist Unit w/ Motorhome Conversion	—	—	555009
2005-96	3500 Series w/ Motorhome Conversion	—	34741	34756
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P52) w/ Motorhome Conversion	—	557003	557004
1996-93	30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ Motorhome Conversion	—	34912	557004
1995-92	G-30 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555036
1995-79	G-30 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	555036
1992-75	G-30 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	90044769  90044770	—	555028 66897 555028 66897

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

\*\* This part number is pair packed/priced.

# RECREATIONAL VEHICLES



OEM



## CHEVROLET — Motorhome Chassis For Class C — Continued

1991-78	G-30 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555038
1978-75	G-30 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	—
1977-70	G-30 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	34803

## CHEVROLET — Motorhome Chassis For Class C Steering Stabilizer

			CYLINDER	COMPLETE KIT
1999-93	30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454		SC2913 <sup>34</sup>	—
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982		555944	—
1993-70	G-30 Series w/o O.E. Steering Stabilizer		SC2915 <sup>33,34</sup>	SA1932

## COACHMEN — Motorhome (Class A)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	557003	557004
---	---	---	--------	--------

## DEXTER TRAILER AXLE

—	4600, 5000 & 7000 lb. Axles	05200300	555001	555001
		19176	555001	555001
		19188	555025	555025

## DODGE — Motorhome Chassis For Class A

1981-77	M6 Motorhome Chassis	3638112 4036892	— 555011	555012 —
1981-73	M & R-300, 400, 500 Motorhome Chassis	3638112 3638631	— 555011	555012 —
1972-63	M-300, M-375 & R-375 Motorhome Chassis	2961043 3633744 3633745	— — 555013	555012 555012 —

## DODGE — Motorhome Chassis For Class B (Recreational Van Conversion)

2003-95	B-3500 Series — Exc. w/ 9000 GVW	—	34831	555038
2003-95	B-3500 Series w/ 9000 GVW	—	555039	555038
1994	B-350 Series — Exc. w/ 9000 GVW	—	34831	555038
1994	B-350 Series w/ 9000 GVW	—	555039	555038
1993-70	B-350 Series — Exc. w/ 4000 lb. Front Axle	—	34831	555038
1993-70	B-350 Series w/ 4000 lb. Front Axle	—	555037	555038

## DODGE — Motorhome Chassis For Class C

2003-95	MB-3500 Motorhome Chassis — Exc. w/ 9000 GVW	—	555037	555038
2003-95	MB-3500 Motorhome Chassis w/ 9000 GVW	—	555039	555038
1994	MB-350 Motorhome Chassis — Exc. w/ 9000 GVW	—	555037	555038
1994	MB-350 Motorhome Chassis w/ 9000 GVW	—	555039	555038
1993-70	MB & BF-300 & 350 Motorhome Chassis — Exc. w/ 4000 lb. Front Axle	—	555037	555038
1993-70	MB & BF-300 & 350 Motorhome Chassis w/ 4000 lb. Front Axle	—	555037	555038
1992-70	MB & BF-300 & 350 Motorhome Chassis w/ Neway Tag Axle TA-3-CA (90044769, 90044770)	90044769 90044770	—	555028 66897 555028 66897

## DYNAMAX (COUNTRY COACH) — Motorhome Chassis For Class A

—	Dynamax Chassis (Allure & Intrigue) 30000 - 32200 GVW w/ Beam Axle	89406 89414	557014 65412 —	— 557015 65401
—	Dynamax Chassis (Allure & Intrigue) 30000 - 32200 GVW w/ Independent Front Axle	—	557013 65433	557015 65401

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

# RECREATIONAL VEHICLES



OEM



## FORD — Motorhome Chassis For Class A

2007-99	Superduty Chassis Motorhome (F53) (Ref. 6.8L V10 Engine)	—	557001	557007
1997-93	Superduty Chassis Motorhome (F53 & F59) w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109016	—	—	555043
1997-88	Superduty Chassis Motorhome (F53 & F59) Over 30 ft. Motorhome (Ref. 7.5L (460) V8 Engine)	—	557001	557002
1976-73	M-400 & M-500 Motorhome Chassis	—	34828	—
1976-57	P-400 & 4000 Motorhome Chassis — Exc. H.D. Springs	—	34803	—
1976-57	P-400 & 4000 Motorhome Chassis w/ H.D. Springs	—	34828	—

## FORD — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
2004-92	Superduty Chassis Motorhome (F53 & F59) w/ OEM No. E8T23E651A, F0TD3E651AA	555949 <sup>34</sup>	—
1991-88	Superduty Chassis Motorhome (F53 & F59) w/o O.E. Steering Stabilizer	SC2912 <sup>33,34</sup>	SA1930

## FORD — Motorhome Chassis For Class B (Recreational Van Conversion)

2007-92	E-350 Series	—	555031	555032
1991-75	E-350 Series	—	555033	555034

## FORD — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
2004-96	E-350 Series w/ OEM No. F2UA3E651AB, F7UZ3E651AA, F7UZ3E651AB, 6C2Z3E651B, 5C2Z3E651BA, 8C2Z3E651B	SC2955 <sup>34</sup>	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer	SC2912 <sup>33,34</sup>	SA1930

## FORD — Motorhome Chassis For Class C

2007-97	E40, E400 Superduty Cutaway Chassis Load Assist Unit w/ Motorhome Conversion	—	—	555010
2004-97	E40, E400 Superduty Cutaway Chassis w/ Motorhome Conversion	—	555031	555032
2004-92	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555010
2004-92	E-350 Series w/ Motorhome Conversion	—	555031	555032
1991-75	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555020
1991-75	E-350 Series w/ Motorhome Conversion	—	555033	555034
1991-75	E-350 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	90044769 90044770	—	555028 66897 555028 66897

## FORD — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
2007-97	E40, E400 Superduty Cutaway Chassis w/ OEM No. F2UA3E651AB, F7UZ3E651AA	SC2955 <sup>34</sup>	—
2004-96	E-350 Series w/ OEM No. F2UA3E651AB, F7UZ3E651AA, F7UZ3E651AB, 6C2Z3E651B, 5C2Z3E651BA, 8C2Z3E651B	SC2955 <sup>34</sup>	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer	SC2912 <sup>33,34</sup>	SA1930

## FORETRAVEL — Motorhome (Class A)

2001-95	U280, U300, U320 (4 Units Req'd Front & Rear)	B461868	555026 66886	555027 66633
---------	---	---------	-----------------	-----------------

## FREIGHTLINER — Custom Chassis Motorhome for Class A

2007-03	XC-Chassis & VC-Chassis (23000 GVW & Greater) ZF-IFS Suspension (Front)  AS120 Suspension (Front) ADL200 Suspension (Rear)	1617144000	557033	—
		1617361000	557033	—
		1618103000	557033	—
		1616737000	557011	—
		1616736000	—	557012
2004-93	XC-Chassis & VC-Chassis (Up To 22000 GVW)	—	557011	557012
2002-01	XCS-Chassis w/ Air Suspension (Freightliner Rear Air)	1616020000	—	557030
		1616093000	557011	—

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

# RECREATIONAL VEHICLES



OEM



## FREIGHTLINER — Custom Chassis Motorhome for Class A — Continued

2002-00	XCS-Chassis 22000 GVW	1615755000 1616043000 —	557028 65453 557028 65453 —	— — 66405
2002-93	XC-Chassis & VC-Chassis (23000 GVW & Greater) AS90, AS120 Beam Suspension (Front) with 1/2 x 1 1/4 Upper Sleeve Mount  AS120, AS140 Beam Suspension (Front) with 3/4 x 1 1/4 Upper Sleeve Mount IFS114 Ind. Suspension (Front)  AD160, AD200 Suspension (Rear)  FAS Airliner (Rear)	B462146M100 B462545M100 — 90045083  B462556M100  1614668000 B462147M100 B462546M100 1616020000	557011 557011 557023 557013 65433 557013 65433 — — — —	— — — — — 557012 557012 557012 557030
2000-97	Powerline (4 Units Req'd on Rear)	BE52581	—	557012
1999-96	MC Chassis	654918 P117099 P117146	66691 — 66691	— 66692 —
1998-92	M-Line w/ Leaf Spring Suspension with Front Axle Stabilizer Bar Forward of Axle with Front Axle Stabilizer Bar Rearward of Axle	— —	— 555011	555012 555012

## FREIGHTLINER — Front-End Diesel Chassis (FRED)

2008-06	All	1618094000 1618095000 1618455000 1618456000 47170000466 471700000467 471700002727 1700002726	557039 — 557039 — 557039 — — 557039	— 557040 — 557040 — 557040 557040 —
---------	-----	---	--	--

## FREIGHTLINER — Motorhome Chassis For Class C

—	FL 70 Series	—	65482	66957
---	--------------	---	-------	-------

## GILLIG — Motorhome Chassis For Class A

—	Gillig 250 & 300 Series Motorhome	90044046 90044683	— —	557020 557020
—	Motorhome w/ O.E. Number	1583470	—	65416
—	Neway Air Suspension	90044769 90044770	— —	557012 557012

## GMC — Motorhome Chassis For Class A

1999-92	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109014	U0109014	—	555043
1999-73	P-3500 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension	—	557003	557004
1999-73	P-3500 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P-3500 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U01094	U0109004	—	34792
1985	P-3500 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1978-73	GMC Front Wheel Drive 24' & 26' Motorhome w/ Front Wheel Drive 4 Units Req'd on Rear	4975412 4975488	— 555045	555046 —
1972-68	P-3500 Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
1972-68	P-3500 Motorhome Chassis w/ 157 in. W.B.	—	34817	—

# RECREATIONAL VEHICLES



OEM



## GMC — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P-3500 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913 <sup>34</sup>	—
1999-75	P-3500 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944	—

## GMC — Motorhome Chassis For Class B (Recreational Van Conversion)

2005-96	3500 Series			
	Front	—	34741	—
	Rear w/ Dual Wheels	—	—	34756
	Load Assist Unit w/ Dual Rear Wheel	—	—	555009
	Rear w/ Single Wheel	—	—	34763
	Load Assist Unit w/ Single Rear Wheel	—	—	58612 <sup>••</sup>
1995-92	G-3500 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-3500 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-3500 Series — Exc. Chopped Van	—	555035	34803

## GMC — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915 <sup>33,34</sup>	SA1932

## GMC — Motorhome Chassis For Class C

2005-96	3500 Series Load Assist Unit w/ Motorhome Conversion	—	—	555009
2005-96	3500 Series w/ Motorhome Conversion	—	34741	34756
1996-93	3500HD Series w/ Independent Front Suspension & Tilt Hood (P52) w/ Motorhome Conversion	—	557003	557004
1996-93	3500HD Series w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ Motorhome Conversion	—	34912	66642
1995-92	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555036
1995-79	G-3500 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	555036
1992-75	G-3500 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	—	—	66636
1991-78	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555038
1978-75	G-3500 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	—
1977-70	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	34803

## GMC — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
1996-93	3500HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982	555944	—
1996-93	3500HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454	SC2913 <sup>34</sup>	—
1991-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915 <sup>33,34</sup>	SA1932

## GMC COACH — Camper Van

—	Motorhome	3178995	65448	65448
---	-----------	---------	-------	-------

## GRANNING SUSPENSION (See Tuthill Technologies)

—	Caster Steering (2 Units Req'd.)	6608	—	66502
---	----------------------------------	------	---	-------

## HOLIDAY RAMBLER — Motorhome (Class A)

2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	557012
2007-04	Models with Roadmaster Chassis R4R, used on Neptune	—	557023	557012
2007-04	Models with Roadmaster Chassis RR8R (Four Units Required Per Axle) used on Endeavor, Ambassador	—	557034	—
2003-02	Models with Roadmaster Chassis RM8C (Four Units Required Per Axle) used on Imperial, Navigator	—	557034	—

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

•• This part number is pair packed/priced.

# RECREATIONAL VEHICLES



OEM



## HOLIDAY RAMBLER — Motorhome (Class A) — Continued

2003-00	Models with Roadmaster Chassis RM4C or used on Ambassador	—	557023	557012
2003-00	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557031	557032
2003-99	Models with Ford E-Superduty/E450 Chassis with 6.8L Gas V10 used on Atlantis <i>For Towing and Hauling</i>	— —	555031 —	555032 555010
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Admiral, Endeavor Gas, Vacationer	—	557001	557007
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Imperial, Navigator	—	555014	555015
2003-94	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Endeavor Diesel, Sceptor	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557001	557002
—	Models with Holiday Rambler Chassis used on Imperial Front	90044794	555028 66897	—
	Drive Axle	U0109007	—	555012
	Tag Axle	U0109008	—	34792
—	Models with Spartan Mountain Master Chassis with Solid Front Axle used on Imperial, Navigator	—	557010 65431	557009 65454

## HOLIDAY RAMBLER — Travel Trailer

—	Trailer w/ 3500-5000 lb. Axles	18864 U01091	555002 555025	555002 555025
---	--------------------------------	-----------------	------------------	------------------

## INTERNATIONAL — Motorhome Chassis For Class A

1975-70	1310 Motorhome Chassis w/ 137 in. & 159 in. W.B. and 10,000 GVW	—	—	34803
1975-70	1510 Motorhome Chassis w/ 178 in. W.B. and 12,000 GVW	—	—	34803

## ISUZU — Motorhome

1995-87	NPR Chassis	—	66717	66618
---------	-------------	---	-------	-------

## ITASCA (Winnebago) — Motorhome (Class C)

—	Models with VW Eurovan Chassis	—	37195	555041
---	--------------------------------	---	-------	--------

## JOHN DEERE — Motorhome Chassis For Class A

1993-86	All	3638112 4036892	— 555011	555012 —
---------	-----	--------------------	-------------	-------------

## MONACO — Motorhome (Class A)

2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	557012
2007-04	Models with Roadmaster Chassis RR8R (Four Units Required Per Axle) used on Diplomat, Knight	—	557034	—
2003-02	Models with Roadmaster Chassis RM8C (Four Units Required Per Axle) used on Dynasty, Signature, Executive	—	557034	—
2003-00	Models with Roadmaster Chassis RM4C or used on Knight	—	557023	557012
2003-00	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Monarch, LaPalma	—	557031	557032
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Monarch, LaPalma	—	557001	557007
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Dynasty, Signature, Executive	—	555014	555015
2003-90	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Diplomat, Windsor, Dynasty	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Monarch, LaPalma	—	557001	557002
—	Models with Spartan Mountain Master Chassis with Solid Front Axle	—	557010 65453	557009 65454

# RECREATIONAL VEHICLES



OEM



## MONACO — Motorhome (Class A) — Continued

—	Royal Coach Bus Conversion on Prevost Chassis Front	630136	65472	—
---	---	--------	-------	---

## MOR-RYDE SUSPENSION

—	Models with O.E. Number	U0109001 U0109004 U0109014 U0109016	555025 34792 555043 555043	555025 34792 555043 555043
---	-------------------------	--	-------------------------------------	-------------------------------------

## OSHKOSH — Motorhome Chassis For Class A

1995-89	V-Line 23000 - 26000 GVW Neway Suspension AR45	1745500	557014 65412	65416
1994-86	M-Line w/ Leaf Spring Suspension with Front Axle Stabilizer Bar Forward of Axle with Front Axle Stabilizer Bar Rearward of Axle	— —	— 555011	555012 555012
1993-85	Coaches w/ Neway Air Suspension	1583470	—	65416

## PEAK CHASSIS — Motorhome Chassis For Class A

2002-95	Alpine (Western RV) AS120 Suspension (Front) ARD200 Suspension (Rear)	B462093 B462092	557023 —	— 557012
---------	---	--------------------	-------------	-------------

## PREVOST CAR — Motorhome Chassis For Class A

—	LeMirage XL 40 ft., 45 ft. & H3-45 VIP Front	630136	65472	—
—	Mirage	010100905 12T113 9210100156 01013401 01013404	65116 65116 65116 65116 65116	— — — — —

## RIALTA (Winnebago) — Motorhome (Class C)

2002-93	Rialta (VW Eurovan Chassis)	—	37195	555041
---------	-----------------------------	---	-------	--------

## SAFARI — Motorhome (Class A)

2007-04	Models with Roadmaster Chassis R4R, used on Simba RD	—	557023	557012
2007-04	Models with Roadmaster Chassis RR8R (Four Units Required Per Axle) used on Cheetah	—	557034	—

## SAFARI MOTOR COACH (SMC) — Motorhome Chassis For Class A

2000-96	Magnum Air B Series (Air-Ride) (4 Units Req'd Front & Rear)	B462092 —	555028 66897 —	— 555029 66897
2000-95	Magnum Blue Max M Series (Velvet Ride Torsion)	B462092 B462093	557026 65432 —	— 557027 65478
1999-93	Magnum Bluestreak Leaf Spring	B462092 B462093	557026 65432 —	— 557027 65478

## SPARTAN — Motorhome Chassis For Class A

2000	Summit (19000 - 22000 GVW)	B461725	—	557018
2000-97	Alpine GT / ST (23000 - 28000 GVW)	B461725	—	557018
2000-97	Mountainmaster / K2 (Verst) w/ Ind. Front Granning Suspension	B462151 B462385	— —	557009 65454 557009 65454

# RECREATIONAL VEHICLES



OEM



## SPARTAN — Motorhome Chassis For Class A — Continued

2000-95	Mountainmaster / K2 / Highlander (Verst) w/ I Beam Front Suspension	B461731	65431 557010	—
		B461732	—	557009 65454
		B462150	65431 557010	—
		B462151	—	557009 65454
1995-91	Mountainmaster MC 2000	B461593 B461594	557010 —	— 557015 65401
—	1000 Motorhome Series	0251SS5 0252SS5 0277SS5 0278SS5	66666 — 66666 —	— 66667 — 66667

## TOYOTA — Motorhome Chassis (Mini) For Class C

1995-85	All	—	34953	34803
---------	-----	---	-------	-------

## TRAIL AIRE

—	Hitch Fifth Wheel Pin Box (Air Ride)	66112 555042	555042 555042	— —
---	--------------------------------------	-----------------	------------------	--------

## TRAVEL TRAILER — Retrofit Kit

—	Axles 1500 - 2500lb. w/ 1 $\frac{1}{4}$ " to 2" Dir. Axle and 1 $\frac{1}{4}$ " Spring Width (Ref. 4 & 5 Lug Wheel)	—	RB-514 <sup>105</sup>	RB-514 <sup>105</sup>
—	Axles 3500 - 4600lb. w/ 2 $\frac{3}{8}$ " Dir. Axle and 1 $\frac{1}{4}$ " Spring Width (Ref. 5 Lug Wheel)	—	RB-511 <sup>105</sup>	RB-511 <sup>105</sup>
—	Axles 5000 - 5600lb. w/ 3" Dia. Axle and 1 $\frac{1}{4}$ " Spring Width (Ref. 6 Lug Wheel)	—	RB-512 <sup>105</sup>	RB-512 <sup>105</sup>
—	Axles 7000lb. w/ 3" Dia. Axle and 1 $\frac{1}{4}$ " Spring Width (Ref. 8 Lug Wheel)	—	RB-512 <sup>105</sup>	RB-512 <sup>105</sup>

## TRAVEL TRAILER — Retrofit Kit Shock

—	Axles 1500 - 3500lb. (10 - 11 $\frac{1}{4}$ " Static Length)	—	555002	555002
—	Axles 2500 - 4600lb. (11 $\frac{3}{8}$ - 13 $\frac{1}{4}$ " Static Length)	—	555003	555003
—	Axles 2500 - 5000lb. (13 $\frac{3}{8}$ - 15 $\frac{1}{2}$ " Static Length)	—	555004	555004
—	Axles 3500 - 7000lb. (15 $\frac{5}{8}$ - 16 $\frac{3}{4}$ " Static Length)	—	555005	555005
—	Axles 4600 - 7000lb. (16 $\frac{7}{8}$ - 20" Static Length)	—	555006	555006

## TUTHILL TECHNOLOGIES

—	101A-AR Rec Vehicle	1816601	—	557015 65401
		1826601	—	557015 65401
—	102A-AR Rec Vehicle Drive Axle	1828601	—	557015 65401

## VIEW (Winnebago) —

2009-07	Models with Freightliner or Dodge Sprinter Rear w/ Dual Wheels Rear w/ Single Wheel	—	—	66417 66414
		—	—	66417 66414
2006-02	Models with Freightliner or Dodge Sprinter Rear w/ Dual Wheels Rear w/ Single Wheel	—	—	66417 66415
		—	—	66417 66415

105 RB513 is to be used with RB511 or RB512 when used on a C-Channel Frame when the channel is In.

# RECREATIONAL VEHICLES



OEM



## VOLKSWAGEN — Motorhome Chassis For Class B (Recreational Van Conversion)

2001-00	Eurovan	—	NA	37196
1999-93	Eurovan	—	37195	37196
1991-80	Vanagon	—	34970	34971

## WINNEBAGO — Motorhome (Class C)

2002-93	Models with VW Eurovan Chassis	—	37195	555041
1991-86	LeSharo (Renault Chassis)	—	71975	—
	Left Units	—	71974	—
	Right Units	—		—

## WORKHORSE — Motorhome Chassis for Class A & C

2008-05	W22	W0005662	557038	—
2007-06	W16 (16000 GVW)	W0007602	557036	—
		W0007608	—	557037
2007-06	W18 (18000 GVW)	W0007603	557036	—
		W0007609	—	557037
2007-05	Universal Floor Option (UFO)	661532	557026	—
		—	65432	65470
2007-05	W24 (24000 GVW)	W0006254	557038	—
		W0006255	—	557032
2003-00	W20, W22 (20000 - 22000 GVW)	S1978	557031	—
		S1981	—	557032
2003-99	P30032 Standard (12,300 GVW)	—	557003	557004
2003-99	P30032 Widetrack (15000, 17000, 18000 GVW)	B461173	557003	—
		B461587	—	557004

## WORKHORSE — Motorhome Chassis for Class A & C Steering Stabilizer

		CYLINDER	COMPLETE KIT
2003-99	P30032 w/ OEM No. BE32645	555944	—