

RECREATIONAL VEHICLES



OEM



ALKO/KOBER TRAILER AXLE

—	Models w/ 4600, 5000 & 7000 lb. Axles	052-003-00 19176 19188	555001 555001 555025	555001 555001 555025
---	---------------------------------------	------------------------------	----------------------------	----------------------------

AMERICAN COACH — Motorhome (Class A)

—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
---	---	---	---	---

BEAVER — Motorhome (Class A)

2000-93	Models with Magnum Chassis - See Safari Motor Coach	—	—	—
1992-88	Models with Gillig Chassis - See Gillig Motorhome Chassis	—	—	—

BLUEBIRD BUS — Motorhome (Class A)

—	WanderLodge Front	90-1968-SP1	65430	—
	Front w/ Ridewell Air Suspension	1750785	65430	—
	Drive Axle	1750793	—	65474
	Tag Axle	1722214	—	74438 65421

CHEVROLET TRUCK — Motorhome Chassis For Class A

1999-95	P12 (P12) Motorhome Chassis	—	65443	65414
1999-92	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109-014	U0109-014	—	555043
1999-73	P30 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension	—	557003	557004
1999-73	P30 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P30 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109-4	U0109-004	—	34792
1985	P30 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1972-68	P30 (P32) Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
1972-68	P30 (P32) Motorhome Chassis w/ 157 in. W.B.	—	34817	—

CHEVROLET TRUCK — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P30 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913 ³⁴	—
1999-75	P30 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944	—

CHEVROLET TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion)

2005-96	3500 Series Front	—	34741	—
	Rear w/ Dual Wheels	—	—	34756
	Load Assist Unit w/ Dual Rear Wheel	—	—	555009
	Rear w/ Single Wheel	—	—	34763
	Load Assist Unit w/ Single Rear Wheel	—	—	58612**
1995-92	G-30 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-30 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-30 Series — Exc. Chopped Van	—	555035	34803

CHEVROLET TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-30 Series w/o O.E. Steering Stabilizer	SC2915 ^{33,34}	SA1932

CHEVROLET TRUCK — Motorhome Chassis For Class C

2005-96	3500 Series Load Assist Unit w/ Motorhome Conversion	—	—	555009
---------	--	---	---	--------

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

** This part number is pair packed/priced.

RECREATIONAL VEHICLES



OEM



CHEVROLET TRUCK — Motorhome Chassis For Class C — Continued

2005-96	3500 Series w/ Motorhome Conversion	—	34741	34756
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P52) w/ Motorhome Conversion	—	557003	557004
1996-93	30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ Motorhome Conversion	—	34912	557004
1995-92	G-30 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555036
1995-79	G-30 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	555036
1995-75	G-30 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	90044769 .90044770	— —	555028 555028
1991-78	G-30 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555038
1978-75	G-30 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	—
1977-70	G-30 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	34803

CHEVROLET TRUCK — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-93	30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454	SC2913 ³⁴	—
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982	555944	—
1993-70	G-30 Series w/o O.E. Steering Stabilizer	SC2915 ^{33,34}	SA1932

COACHMEN — Motorhome (Class A)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	557003	557004
—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

COACHMEN — Motorhome (Class C)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class C) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class C) Chassis	—	—	—

COUNTRY COACH — Motorhome (Class A)

—	Models with Dynamax Chassis - See Dynamax Motorhome Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Gillig Chassis - See Gillig Motorhome Chassis	—	—	—
—	Models with Prevost Chassis - See Prevost Car Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—

DAMON — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

DEXTER TRAILER AXLE

—	Models w/ 4600, 5000 & 7000 lb. Axles	052-003-00 19176 19188	555001 555001 555025	555001 555001 555025
---	---------------------------------------	------------------------------	----------------------------	----------------------------

DODGE TRUCK — Motorhome Chassis For Class A

1981-77	M6 Motorhome Chassis	3638112 4036892	— 555011	555012 —
1981-73	M & R-300, 400, 500 Motorhome Chassis	3638112 3638631	— 555011	555012 —
1972-63	M-300, M-375 & R-375 Motorhome Chassis	2961043 3633744 3633745	— — 555013	555012 555012 —

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

RECREATIONAL VEHICLES



OEM



DODGE TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion)

2003-95	B-3500 Series — Exc. w/ 9000 GVW	—	34831	555038
2003-95	B-3500 Series w/ 9000 GVW	—	555039	555038
1994	B-350 Series — Exc. w/ 9000 GVW	—	34831	555038
1994	B-350 Series w/ 9000 GVW	—	555039	555038
1993-70	B-350 Series — Exc. w/ 4000 lb. Front Axle	—	34831	555038
1993-70	B-350 Series w/ 4000 lb. Front Axle	—	555037	555038

DODGE TRUCK — Motorhome Chassis For Class C

2003-95	MB-3500 Motorhome Chassis — Exc. w/ 9000 GVW	—	555037	555038
2003-95	MB-3500 Motorhome Chassis w/ 9000 GVW	—	555039	555038
1994	MB-350 Motorhome Chassis — Exc. w/ 9000 GVW	—	555037	555038
1994	MB-350 Motorhome Chassis w/ 9000 GVW	—	555039	555038
1993-70	MB & BF-300 & 350 Motorhome Chassis — Exc. w/ 4000 lb. Front Axle	—	555037	555038
1993-70	MB & BF-300 & 350 Motorhome Chassis w/ 4000 lb. Front Axle	—	555037	555038
1992-70	MB & BF-300 & 350 Motorhome Chassis w/ Neway Tag Axle TA-3-CA (90044769, 90044770)	90044769 90044770	— —	555028 555028

DYNAMAX — Motorhome (Class C)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class C) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class C) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Motorhome (Class C) Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

DYNOMAX (COUNTRY COACH) — Motorhome Chassis For Class A

—	Dynomax Chassis (Allure & Intrique) 30000 - 32200 GVW w/ Beam Axle	89406 89414	557014 —	— 557015
—	Dynomax Chassis (Allure & Intrique) 30000 - 32200 GVW w/ Independent Front Axle	—	557013	557015

FLEETWOOD — Motorhome (Class A)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Oshkosh Chassis - See Oshkosh Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

FLEETWOOD — Motorhome (Class C)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class C) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class C) Chassis	—	—	—

FORD TRUCK — Motorhome Chassis For Class A

2007-99	Superduty Chassis Motorhome (F53) (Ref. 6.8L V10 Engine)	—	557001	557007
1997-93	Superduty Chassis Motorhome (F53 & F59) w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109-016	—	—	555043
1997-88	Superduty Chassis Motorhome (F53 & F59) Over 30 ft. Motorhome (Ref. 7.5L (460) V8 Engine)	—	557001	557002
1976-73	M-400 & M-500 Motorhome Chassis	—	34828	—
1976-57	P-400 & 4000 Motorhome Chassis — Exc. H.D. Springs	—	34803	—
1976-57	P-400 & 4000 Motorhome Chassis w/ H.D. Springs	—	34828	—

FORD TRUCK — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
2004-92	Superduty Chassis Motorhome (F53 & F59) w/ OEM No. E8T2-3E651-A, F0TD-3E651-AA	555949 ³⁴	—
1991-88	Superduty Chassis Motorhome (F53 & F59) w/o O.E. Steering Stabilizer	SC2912 ^{33,34}	SA1930

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

RECREATIONAL VEHICLES



OEM



FORD TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion)

2007-92	E-350 Series	—	555031	555032
1991-75	E-350 Series	—	555033	555034

FORD TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
2004-96	E-350 Series w/ OEM No. F2UA-3E651-AB, F7UZ-3E651-AA	SC2955 ³⁴	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer	SC2912 ^{33,34}	SA1930

FORD TRUCK — Motorhome Chassis For Class C

2007-97	E40, E400 Superduty Cutaway Chassis Load Assist Unit w/ Motorhome Conversion	—	—	555010
2004-97	E40, E400 Superduty Cutaway Chassis w/ Motorhome Conversion	—	555031	555032
2004-92	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555010
2004-92	E-350 Series w/ Motorhome Conversion	—	555031	555032
1991-75	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555020
1991-75	E-350 Series w/ Motorhome Conversion	—	555033	555034
1991-75	E-350 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	90044769 90044770	— —	555028 555028

FORD TRUCK — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
2007-97	E40, E400 Superduty Cutaway Chassis w/ OEM No. F2UA-3E651-AB, F7UZ-3E651-AA	SC2955 ³⁴	—
2004-96	E-350 Series w/ OEM No. F2UA-3E651-AB, F7UZ-3E651-AA	SC2955 ³⁴	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer	SC2912 ^{33,34}	SA1930

FORETRAVEL — Motorhome (Class A)

2001-95	U280, U300, U320 (4 Units Req'd Front & Rear)	B46-1868	555026	555027
---------	---	----------	--------	--------

FREIGHTLINER — Custom Chassis Motorhome for Class A

2007-03	XC-Chassis & VC-Chassis (23000 GVW & Greater) ZF-IFS Suspension (Front)	16-17144-000	557033	—
		16-17361-000	557033	—
		16-18103-000	557033	—
		16-16737-000	557011	—
		16-16736-000	—	557012
2004-93	XC-Chassis & VC-Chassis (Up To 22000 GVW)	—	557011	557012
		16-16020-000	—	557030
2002-01	XCS-Chassis w/ Air Suspension (Freightliner Rear Air)	16-16093-000	557011	—
		16-15592-000	66405	—
2002-00	XCS-Chassis 22000 GVW	16-15755-000	557028	—
		16-16043-000	557028	—
		16-16043-000	557028	—
2002-93	XC-Chassis & VC-Chassis (23000 GVW & Greater) AS90, AS120 Beam Suspension (Front) with ½ x 1¼ Upper Sleeve Mount AS120, AS140 Beam Suspension (Front) with ¾ x 1¼ Upper Sleeve Mount IFS114 Ind. Suspension (Front) AD160, AD200 Suspension (Rear) FAS Airliner (Rear)	B46-2146-M100	557011	—
		B46-2545-M100	557011	—
		—	557023	—
		90045083	557013	—
		B46-2556-M100	557013	—
		16-14668-000	—	557012
		B46-2147-M100	—	557012
		B46-2546-M100	—	557012
		16-16020-000	—	557030
		2000-97	Powerline (4 Units Req'd on Rear)	BE5-2581
1999-96	MC Chassis	654918	66691	—
		P117099	—	66692
		P117146	66691	—

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

RECREATIONAL VEHICLES



OEM



FREIGHTLINER — Custom Chassis Motorhome for Class A — Continued

1998-92	M-Line w/ Leaf Spring Suspension with Front Axle Stabilizer Bar Forward of Axle with Front Axle Stabilizer Bar Rearward of Axle	— —	— 555011	555012 555012
---------	---	--------	-------------	------------------

FREIGHTLINER — Motorhome Chassis For Class C

—	FL 70 Series	—	65482	66957
---	--------------	---	-------	-------

GEORGIE BOY — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

GILLIG — Motorhome Chassis For Class A

—	Gillig 250 & 300 Series Motorhome	90044046 90044683	— —	557020 557020
—	Models w/ Neway Air Suspension	90044769 90044770	— —	557012 557012
—	Motorhome w/ O.E. Number	1583470 90045084	— —	557022 65464

GMC COACH — Camper Van

—	Motorhome	3178995	65448	65448
---	-----------	---------	-------	-------

GMC TRUCK — Motorhome Chassis For Class A

1999-92	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109-014	U0109-014	—	555043
1999-73	P-3500 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension	—	557003	557004
1999-73	P-3500 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P-3500 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109-4	U0109-004	—	34792
1985	P-3500 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1978-73	GMC Front Wheel Drive 24' & 26' Motorhome w/ Front Wheel Drive 4 Units Req'd on Rear	4975412 4975488	— 555045	555046 —
1972-68	P-3500 Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
1972-68	P-3500 Motorhome Chassis w/ 157 in. W.B.	—	34817	—

GMC TRUCK — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P-3500 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913 ³⁴	—
1999-75	P-3500 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944	—

GMC TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion)

2005-96	3500 Series Front Rear w/ Dual Wheels <i>Load Assist Unit w/ Dual Rear Wheel</i> Rear w/ Single Wheel <i>Load Assist Unit w/ Dual Rear Wheel</i>	— — — — —	34741 — — — —	— 34756 555009 34763 58612 ³⁴
1995-92	G-3500 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-3500 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-3500 Series — Exc. Chopped Van	—	555035	34803

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.
³⁴ This part number is pair packed/priced.

RECREATIONAL VEHICLES



OEM



GMC TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915 ^{33,34}	SA1932

GMC TRUCK — Motorhome Chassis For Class C

2005-96	3500 Series Load Assist Unit w/ Motorhome Conversion	—	—	555009
2005-96	3500 Series w/ Motorhome Conversion	—	34741	34756
1996-93	3500HD Series w/ Independent Front Suspension & Tilt Hood (P52) w/ Motorhome Conversion	—	557003	557004
1996-93	3500HD Series w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ Motorhome Conversion	—	34912	66642
1995-92	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555036
1995-79	G-3500 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	555036
1992-75	G-3500 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	—	—	66636
1991-78	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555038
1978-75	G-3500 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	—
1977-70	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	34803

GMC TRUCK — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
1996-93	3500HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982	555944	—
1996-93	3500HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454	SC2913 ³⁴	—
1991-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915 ^{33,34}	SA1932

GRANNING SUSPENSION (See Tuthill Technologies)

—	Models w/ Caster Steering (2 Units Req'd.)	6608	—	66502
---	--	------	---	-------

GULFSTREAM — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

HOLIDAY RAMBLER — Motorhome (Class A)

2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	557012
2007-04	Models with Roadmaster Chassis R4R, used on Neptune	—	557023	557012
2007-04	Models with Roadmaster Chassis RR8R (Four Units Required Per Axle) used on Endeavor, Ambassador	—	557034	557035
2003-02	Models with Roadmaster Chassis RM8C (Four Units Required Per Axle) used on Imperial, Navigator	—	557034	557035
2003-00	Models with Roadmaster Chassis RM4C or used on Ambassador	—	557023	557012
2003-00	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557031	557032
2003-99	Models with Ford E-Superduty/E450 Chassis with 6.8L Gas V10 used on Atlantis For Towing and Hauling	— —	555031 —	555032 555010
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Admiral, Endeavor Gas, Vacationer	—	557001	557007
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Imperial, Navigator	—	555014	555015
2003-94	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Endeavor Diesel, Sceptor	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557001	557002
—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	—	—

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

RECREATIONAL VEHICLES



OEM



HOLIDAY RAMBLER — Motorhome (Class A) — Continued

—	Models with Holiday Rambler Chassis used on Imperial Front Drive Axle Tag Axle	90044794 U0109-007 U0109-008	555028 — —	— 555012 34792
—	Models with Oshkosh Chassis - See Oshkosh Motorhome Chassis	—	—	—
—	Models with Spartan Mountain Master Chassis with Solid Front Axle used on Imperial, Navigator	—	557010	557009

HOLIDAY RAMBLER — Travel Trailer

—	Trailer w/ 3500-5000 lb. Axles	18864 U0109-1	555002 555025	555002 555025
---	--------------------------------	------------------	------------------	------------------

INTERNATIONAL TRUCK — Motorhome Chassis For Class A

1975-70	1310 Motorhome Chassis w/ 137 in. & 159 in. W.B. and 10,000 GVW	—	—	34803
1975-70	1510 Motorhome Chassis w/ 178 in. W.B. and 12,000 GVW	—	—	34803

ISUZU — Motorhome

1995-87	NPR Chassis	—	66717	66618
---------	-------------	---	-------	-------

ITASCA (Winnebago) — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

ITASCA (Winnebago) — Motorhome (Class C)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class C) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class C) Chassis	—	—	—
—	Models with VW Eurovan Chassis	—	37195	555041

JAYCO — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

JOHN DEERE — Motorhome Chassis For Class A

1993-86	All	3638112 4036892	— 555011	555012 —
---------	-----	--------------------	-------------	-------------

MONACO — Motorhome (Class A)

2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	557012
2007-04	Models with Roadmaster Chassis RR8R (Four Units Required Per Axle) used on Diplomat, Knight	—	557034	557035
2003-02	Models with Roadmaster Chassis RM8C (Four Units Required Per Axle) used on Dynasty, Signature, Executive	—	557034	557035
2003-00	Models with Roadmaster Chassis RM4C or used on Knight	—	557023	557012
2003-00	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Monarch, LaPalma	—	557031	557032
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Monarch, LaPalma	—	557001	557007
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Dynasty, Signature, Executive	—	555014	555015
2003-90	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Diplomat, Windsor, Dynasty	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Monarch, LaPalma	—	557001	557002
—	Models with Spartan Mountain Master Chassis with Solid Front Axle	—	557010	557009

RECREATIONAL VEHICLES



OEM



MONACO — Motorhome (Class A) — Continued

—	Royal Coach Bus Conversion on Prevost Chassis Front	630136	65472	—
---	---	--------	-------	---

MOR-RYDE SUSPENSION

—	Models with O.E. Number	U0109-001 U0109-004 U0109-014 U0109-016	555025 34792 555043 555043	555025 34792 555043 555043
---	-------------------------	--	-------------------------------------	-------------------------------------

NATIONAL RV — Motorhome (Class A)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	—	—
—	Models with Dynamax Chassis - See Dynamax Motorhome Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

NEWMAR KOUNTRY — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

OSHKOSH — Motorhome Chassis For Class A

1995-89	V-Line 23000 - 26000 GVW Neway Suspension AR45 Neway Suspension ARD125	1745500 1583470	557014 —	— 557022
1994-86	M-Line w/ Leaf Spring Suspension with Front Axle Stabilizer Bar Forward of Axle with Front Axle Stabilizer Bar Rearward of Axle	— —	— 555011	555012 555012
1993-85	Coaches w/ Neway Air Suspension	1583470	—	557022

PEAK CHASSIS — Motorhome Chassis For Class A

2002-95	Alpine (Western RV) AS120 Suspension (Front) ARD200 Suspension (Rear)	B46-2093 B46-2092	557023 —	— 557012
---------	---	----------------------	-------------	-------------

PREVOST CAR — Motorhome Chassis For Class A

—	LeMirage XL 40 ft., 45 ft. & H3-45 VIP Front	630136	65472	—
—	Mirage	01-0100-905 12T-1-13 92-101-00156 01013401 01013404	65116 65116 65116 65116 65116	— — — — —

REXHALL — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

RIALTA (Winnebago) — Motorhome (Class C)

2002-93	Rialta (VW Eurovan Chassis)	—	37195	555041
---------	-----------------------------	---	-------	--------

ROADMASTER (MONACO) — Motorhome Chassis For Class A

—	Models with Roadmaster Chassis - See Monaco Motorhome Chassis	—	—	—
---	---	---	---	---

RECREATIONAL VEHICLES



OEM



SAFARI — Motorhome (Class A)

2007-04	Models with Roadmaster Chassis R4R, used on Simba RD	—	557023	557012
2007-04	Models with Roadmaster Chassis RR8R (Four Units Required Per Axle) used on Cheetah	—	557034	557035
—	Models with Magnum Chassis - See Safari Motor Coach	—	—	—
—	Models with Roadmaster Chassis - See Monaco Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

SAFARI MOTOR COACH (SMC) — Motorhome Chassis For Class A

2000-96	Magnum Air B Series (Air-Ride) (4 Units Req'd Front & Rear)	B46-2092 —	555028 —	— 555029
2000-95	Magnum Blue Max M Series (Velvet Ride Torsion)	B46-2092 B46-2093	557026 —	— 557027
1999-93	Magnum Bluestreak Leaf Spring	B46-2092 B46-2093	557026 —	— 557027

SPARTAN — Motorhome Chassis For Class A

2000	Summit (19000 - 22000 GVW)	B46-1725	—	557018
2000-97	Alpine GT / ST (23000 - 28000 GVW)	B46-1725	—	557018
2000-97	Mountainmaster / K2 (Verst) w/ Ind. Front Granning Suspension	B46-2151 B46-2385	— —	557009 557009
2000-95	Mountainmaster / K2 / Highlander (Verst) w/ I Beam Front Suspension	B46-1731 B46-1732 B46-2150 B46-2151	557010 — 557010 —	— 557009 — 557009
1995-91	Mountainmaster MC 2000	B46-1593 B46-1594	557010 —	— 557015
—	1000 Motorhome Series	0251-SS5 0252-SS5 0277-SS5 0278-SS5	66666 — 66666 —	— 66667 — 66667

TIFFIN — Motorhome (Class A)

—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

TOYOTA TRUCK — Motorhome Chassis (Mini) For Class C

1995-85	All	—	34953	34803
---------	-----	---	-------	-------

TRAIL AIRE

—	Hitch Fifth Wheel Pin Box (Air Ride)	66112 555042	555042 555042	— —
---	--------------------------------------	-----------------	------------------	--------

TRAVEL TRAILER — Retrofit Kit Shock

—	Axles 1500 - 3500lb. (10 - 11¼" Static Length)	—	555002	555002
—	Axles 2500 - 4600lb. (11⅝ - 13¼" Static Length)	—	555003	555003
—	Axles 2500 - 5000lb. (13⅜ - 15½" Static Length)	—	555004	555004
—	Axles 3500 - 7000lb. (15⅝ - 16¾" Static Length)	—	555005	555005
—	Axles 4600 - 7000lb. (16⅞ - 20" Static Length)	—	555006	555006

TUTHILL TECHNOLOGIES

—	101A-AR Rec Vehicle	18166-01 18266-01	— —	557015 557015
—	102A-AR Rec Vehicle Drive Axle	18286-01	—	557015

RECREATIONAL VEHICLES



OEM



ULTMATE (Winnebago) — Motorhome (Class A)

—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
---	---	---	---	---

VOLKSWAGEN TRUCK — Motorhome Chassis For Class B (Recreational Van Conversion)

2001-00	Eurovan	—	NA	37196
1999-93	Eurovan	—	37195	37196
1991-80	Vanagon	—	34970	34971

WINNEBAGO — Motorhome (Class A)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class A) Chassis	—	—	—
—	Models with Freightliner Chassis - See Freightliner Custom Motorhome Chassis	—	—	—
—	Models with Spartan Chassis - See Spartan Motorhome Chassis	—	—	—
—	Models with Workhorse Chassis - See Workhorse Motorhome Chassis	—	—	—

WINNEBAGO — Motorhome (Class C)

2002-93	Models with VW Eurovan Chassis	—	37195	555041
1991-86	LeSharo (Renault Chassis)			
	Left Units	—	71975	—
	Right Units	—	71974	—
—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class C) Chassis	—	—	—
—	Models with Ford Chassis - See Ford Motorhome (Class C) Chassis	—	—	—

WORKHORSE — Motorhome Chassis for Class A & C

2007-06	W16 (16000 GVW)	W0007602	557036	—
		W0007608	—	557037
2007-06	W18 (18000 GVW)	W0007603	557036	—
		W0007609	—	557037
2007-05	Universal Floor Option (UFO)	66153-2	557026	—
		—	—	65470
2007-05	W24 (24000 GVW)	W0006254	557038	—
		W0006255	—	557032
2003-00	W20, W22 (20000 - 22000 GVW)	S1978	557031	—
		S1981	—	557032
2003-99	P30032 Standard (12,300 GVW)	—	557003	557004
2003-99	P30032 Widetrack (15000, 17000, 18000 GVW)	B46-1173	557003	—
		B46-1587	—	557004

WORKHORSE — Motorhome Chassis for Class A & C Steering Stabilizer

		CYLINDER	COMPLETE KIT
2003-99	P30032 w/ OEM No. BE3-2645	555944	—