



RECREATIONAL VEHICLES		OEM		
ALKO/KOBER TRAILER AXLE				
—	4600, 5000 & 7000 lb. Axles	05200300 19176 19188	555001 555001 555025	555001 555001 555025
BLUEBIRD BUS — Motorhome (Class A)				
—	WanderLodge Front Front w/ Ridewell Air Suspension Drive Axle Tag Axle	901968SP1 1750785 1750793 1722214	65430 65430 — —	— — 65474 or 74438 65421
CHEVROLET — Motorhome Chassis For Class A				
1999-95	P12 (P12) Motorhome Chassis	—	—	65414
1999-92	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109014	U0109014	—	555043
1999-73	P30 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension	—	557003	557004
	P30 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P30 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U01094	U0109004	—	34792
1985	P30 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1972-68	P30 (P32) Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
	P30 (P32) Motorhome Chassis w/ 157 in. W.B.	—	34817	—
CHEVROLET — Motorhome Chassis For Class A — Steering Stabilizer				
			CYLINDER	COMPLETE KIT
1999-85	P30 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454		SC2913 ^[24]	—
1999-75	P30 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838		555944 ^[24]	—
CHEVROLET — Motorhome Chassis For Class B (Recreational Van Conversion)				
2013-03	3500 Series Single Rear Wheel Dual Rear Wheels	— —	34530 34530	34531 34532
2002-96	3500 Series Dual Rear Wheel Load Assist Unit w/ Dual Rear Wheel	— —	34530 34530	34756 555009
1995-92	G-30 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-30 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-30 Series — Exc. Chopped Van	—	555035	34803
CHEVROLET — Motorhome Chassis For Class B (Recreational Van Conversion) — Steering Stabilizer				
			CYLINDER	COMPLETE KIT
1993-70	G-30 Series w/o O.E. Steering Stabilizer		SC2915 ^[23] ^[24]	SA1932
CHEVROLET — Motorhome Chassis For Class C				
2016-09	3500 Cutaway Van w/ Lowered Rear Spring 3500 Cutaway Van w/o Lowered Rear Spring 3500 Express Series — Exc. Cutaway Van	— — —	34530 34530 34530	34532 34531 34763
2008-03	3500 Express Series	—	34530	34763
2002-96	3500 Express Series — Exc. Models w/ Dual Rear Wheels 3500 Express Series w/ Rear Dual Weels	— —	34741 34741	34763 34756
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) 30HD w/ Straight Front Axle & Tilt Hood (P42 / P62)	— —	34736 34912	— 34960

^[23] Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

^[24] 19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER

COMMERCIAL
VEHICLES

RECREATIONAL
VEHICLES

SCHOOL
BUSES

BUSES &
COACHES

TRUCKS, TRAILERS
& SUSPENSIONS

INTERCHANGES

NUMERICAL
LISTINGS

MOUNTING &
LENGTH BY PART

MOUNTING &
LENGTH BY MOUNT

RECREATIONAL VEHICLES

OEM



CHEVROLET — Motorhome Chassis For Class C (Cont.)

1995-92	G-30 Series — Exc. Chopped Van & Extended Van (G39) Load Assist Unit	—	34839	34783
	G-30 Extended Van (G39) Load Assist Unit	—	555035	555036
1995-79	G-30 Series Chopped Van w/ Rear Dual Weels Load Assist Unit	—	34839	34783
		—	555035	555036
1991-78	G-30 Series — Exc. Chopped Van Load Assist Unit	—	34839	34910
		—	555035	555038
1978-75	G-30 Series Chopped Van w/ Rear Dual Wheels Load Assist Unit	—	34839	—
		—	555035	—
1977-70	G-30 Series — Exc. Chopped Van Load Assist Unit	—	34839	34803
		—	555035	—

CHEVROLET — Motorhome Chassis For Class C — Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-93	30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454	SC2913 ³⁴	—
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982	555944 ³⁴	—
1993-70	G-30 Series w/o O.E. Steering Stabilizer	SC2915 ³³ ³⁴	SA1932

COACHMEN — Motorhome (Class A)

—	Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis	—	557003	557004
---	---	---	--------	--------

DEXTER TRAILER AXLE

—	4600, 5000 & 7000 lb. Axles	05200300	555001	555001
		19176	555001	555001
		19188	555025	555025

DODGE — Motorhome Chassis For Class A

1981-77	M6 Motorhome Chassis	3638112	—	—
		4036892	555011	—
1981-73	M & R-300, 400, 500 Motorhome Chassis	3638112	—	—
		3638631	555011	—
1972-63	M-300, M-375 & R-375 Motorhome Chassis	2961043	—	—
		3633744	—	—

DODGE — Motorhome Chassis For Class B (Recreational Van Conversion)

2003-95	B-3500 Series — Exc. w/ 9000 GVW	—	34831	555038
	B-3500 Series w/ 9000 GVW	—	555039	555038
1994	B-350 Series — Exc. w/ 9000 GVW	—	34831	555038
	B-350 Series w/ 9000 GVW	—	555039	555038
1993-70	B-350 Series — Exc. w/ 4000 lb. Front Axle	—	34831	555038
	B-350 Series w/ 4000 lb. Front Axle	—	555037	555038

DODGE — Motorhome Chassis For Class C

2003-95	MB-3500 Motorhome Chassis — Exc. w/ 9000 GVW	—	555037	555038
	MB-3500 Motorhome Chassis w/ 9000 GVW	—	555039	555038
1994	MB-350 Motorhome Chassis — Exc. w/ 9000 GVW	—	555037	555038
	MB-350 Motorhome Chassis w/ 9000 GVW	—	555039	555038
1993-70	MB & BF-300 & 350 Motorhome Chassis — Exc. w/ 4000 lb. Front Axle	—	555037	555038
	MB & BF-300 & 350 Motorhome Chassis w/ 4000 lb. Front Axle	—	555037	555038
1992-70	MB & BF-300 & 350 Motorhome Chassis w/ Neway Tag Axle TA-3-CA (90044769, 90044770)	90044769	—	66897
		90044770	—	66897

³³ Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

³⁴ 19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER

RECREATIONAL VEHICLES

OEM



COMMERCIAL
VEHICLES

DYNAMAX (COUNTRY COACH) — Motorhome Chassis For Class A

—	Dynamax Chassis (Allure & Intrique) 30000 - 32200 GVW w/ Beam Axle	89406	557014 65412	—
	Dynamax Chassis (Allure & Intrique) 30000 - 32200 GVW w/ Independent Front Axle	89414	—	65401
		—	65433	65401

RECREATIONAL
VEHICLES

FORD — Motorhome Chassis For Class A

2019-99	Superduty Chassis Motorhome (F53)	—	557001	557007
1997-93	Superduty Chassis Motorhome (F53 & F59) w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109016	—	—	555043
1997-88	Superduty Chassis Motorhome (F53 & F59) Over 30 ft. Motorhome (Ref. 7.5L (460) V8 Engine)	—	557001	557002
1976-73	M-400 & M-500 Motorhome Chassis	—	34828	—
1976-57	P-400 & 4000 Motorhome Chassis — Exc. H.D. Springs	—	34803	—
	P-400 & 4000 Motorhome Chassis w/ H.D. Springs	—	34828	—

SCHOOL
BUSES

FORD — Motorhome Chassis For Class A — Steering Stabilizer

			CYLINDER	COMPLETE KIT
2004-92	Superduty Chassis Motorhome (F53 & F59) w/ OEM No. E8T23E651A, F0TD3E651AA		555949 ^[34]	—
1991-88	Superduty Chassis Motorhome (F53 & F59) w/o O.E. Steering Stabilizer		SC2912 ^{[33][34]}	SA1930

BUSES &
COACHES

FORD — Motorhome Chassis For Class B (Recreational Van Conversion)

2007-92	E-350 Series	—	555031	555032
1991-75	E-350 Series	—	555033	555034

FORD — Motorhome Chassis For Class B (Recreational Van Conversion) — Steering Stabilizer

			CYLINDER	COMPLETE KIT
2004-96	E-350 Series w/ OEM No. F2UA3E651AB, F7UZ3E651AA, F7UZ3E651AB, 6C2Z3E651B, 5C2Z3E651BA, 8C2Z3E651B		SC2955 ^[34]	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer		SC2912 ^{[33][34]}	SA1930

TRUCKS, TRAILERS
& SUSPENSIONS

FORD — Motorhome Chassis For Class C

2017-97	E40, E400, E450 Superduty Cutaway Chassis Load Assist Unit w/ Motorhome Conversion	—	—	555010
	E40, E400 Superduty Cutaway Chassis w/ Motorhome Conversion	—	555031	555032
2017-92	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555010
	E-350 Series w/ Motorhome Conversion	—	555031	555032
1991-75	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555020
	E-350 Series w/ Motorhome Conversion	—	555033	555034
	E-350 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	90044769	—	66897
		90044770	—	66897

INTERCHANGES

FORD — Motorhome Chassis For Class C — Steering Stabilizer

			CYLINDER	COMPLETE KIT
2007-97	E40, E400 Superduty Cutaway Chassis w/ OEM No. F2UA3E651AB, F7UZ3E651AA		SC2955 ^[34]	—
2004-96	E-350 Series w/ OEM No. F2UA3E651AB, F7UZ3E651AA, F7UZ3E651AB, 6C2Z3E651B, 5C2Z3E651BA, 8C2Z3E651B		SC2955 ^[34]	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer		SC2912 ^{[33][34]}	SA1930

NUMERICAL
LISTINGS

FORETRAVEL — Motorhome (Class A)

2001-95	U280, U300, U320 (4 Units Req'd Front & Rear)	B461868	66886	66633
---------	---	---------	-------	-------

MOUNTING &
LENGTH BY PART

FREIGHTLINER — Custom Chassis Motorhome for Class A

2015-01	XCS-Chassis w/ Freightliner Air Suspension	1616020000	—	557046
2012-03	XC-Chassis & VC-Chassis (23000 GVW & Greater)			
	AS120 Suspension (Front)	1616737000	557011	—
	ADL200 Suspension (Rear)	1616736000	—	557012

MOUNTING &
LENGTH BY MOUNT

^[33] Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

^[34] 19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER

RECREATIONAL VEHICLES

OEM



FREIGHTLINER — Custom Chassis Motorhome for Class A (Cont.)

2004-93	XC-Chassis & VC-Chassis (Up To 22000 GVW)	— 1616093000	557011 557011	557012 —
2002-00	XCS-Chassis 22000 GVW	1615755000 1616043000 —	65453 65453 —	— — 66405
2002-93	XC-Chassis & VC-Chassis (23000 GVW & Greater) AS90, AS120 Beam Suspension (Front) with ½ x 1¾ Upper Sleeve Mount AS120, AS140 Beam Suspension (Front) with ¾ x 1¾ Upper Sleeve Mount IFS114 Ind. Suspension (Front) AD160, AD200 Suspension (Rear)	B462146M100 B462545M100 — 90045083 B462556M100 1614668000 B462147M100 B462546M100	557011 557011 557023 65433 65433 — — —	— — — — — 557012 557012 557012
2000-97	Powerline (4 Units Req'd on Rear)	BE52581	—	557012
1999-96	MC Chassis	654918 P117099 P117146	66691 — 66691	— 66692 —
1998-92	M-Line w/ Leaf Spring Suspension with Front Axle Stabilizer Bar Forward of Axle with Front Axle Stabilizer Bar Rearward of Axle	— —	— 555011	— —

FREIGHTLINER — Front-End Diesel Chassis (FRED)

2008-06	All	1618094000 1618455000 47170000466 1700002726	557039 557039 557039 557039	— — — —
---------	-----	---	--------------------------------------	------------------

FREIGHTLINER — Motorhome Chassis For Class C

—	FL 70 Series	—	65482	66957
---	--------------	---	-------	-------

GILLIG — Motorhome Chassis For Class A

—	Motorhome w/ O.E. Number Neway Air Suspension	1583470 90044769 90044770	— — —	65416 557012 557012
---	--	---------------------------------	-------------	---------------------------

GMC — Motorhome Chassis For Class A

1999-92	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109014	U0109014	—	555043
1999-73	P-3500 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension P-3500 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	— —	557003 557003	557004 557004
1997-86	P-3500 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U010904	U0109004	—	34792
1985	P-3500 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1978-73	GMC Front Wheel Drive 24' & 26' Motorhome w/ Front Wheel Drive (4 Units Req'd on Rear)	4975412	—	555046
1972-68	P-3500 Motorhome Chassis — Exc. 157 in. W.B. P-3500 Motorhome Chassis w/ 157 in. W.B.	— —	34817 34817	34803 —

GMC — Motorhome Chassis For Class A — Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P-3500 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913 [ⓧ]	—
1999-75	P-3500 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944 [ⓧ]	—

[ⓧ] 19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER

RECREATIONAL VEHICLES

OEM



COMMERCIAL
VEHICLES

GMC — Motorhome Chassis For Class B (Recreational Van Conversion)

2013-03	3500 Series Single Rear Wheel Dual Rear Wheels	— —	34530 34530	34531 34532
2002-96	3500 Series Dual Rear Wheels Load Assist Unit w/ Dual Rear Wheel	— —	34530 34530	34756 555009
1995-92	G-3500 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-3500 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-3500 Series — Exc. Chopped Van	—	555035	34803

RECREATIONAL
VEHICLES

GMC — Motorhome Chassis For Class B (Recreational Van Conversion) — Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915 ^[33] ^[34]	SA1932

SCHOOL
BUSES

GMC — Motorhome Chassis For Class C

2013-09	3500 Cutaway Van w/ Lowered Rear Spring 3500 Cutaway Van w/o Lowered Rear Spring 3500 Savana Series — Exc. Cutaway Van	— — —	34530 34530 34530	34532 34531 34763
2008-03	3500 Savana Series	—	34530	34763
2002-96	3500 Savana Series — Exc. Models w/ Dual Rear Wheels 3500 Savana Series w/ Rear Dual Weels	— —	34741 34741	34763 34756
1996-93	3500HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) 3500HD w/ Straight Front Axle & Tilt Hood (P42 / P62)	— —	34736 34912	— 34960
1995-92	G-3500 Series — Exc. Chopped Van & Extended Van (G39) Load Assist Unit G-3500 Extended Van (G39) Load Assist Unit	— — — —	34839 555035 34839 555035	34783 555036 34783 555036
1995-79	G-3500 Series Chopped Van w/ Rear Dual Weels Load Assist Unit	— —	34839 555035	34929 555036
1991-78	G-3500 Series — Exc. Chopped Van Load Assist Unit	— —	34839 555035	34910 555038
1978-75	G-3500 Series Chopped Van w/ Rear Dual Wheels Load Assist Unit	— —	34839 555035	— —
1977-70	G-3500 Series — Exc. Chopped Van Load Assist Unit	— —	34839 555035	34803 —

BUSES &
COACHES

TRUCKS, TRAILERS
& SUSPENSIONS

INTERCHANGES

GMC — Motorhome Chassis For Class C — Steering Stabilizer

		CYLINDER	COMPLETE KIT
1996-93	3500HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982 3500HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454	555944 ^[34] SC2913 ^[34]	— —
1991-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915 ^[33] ^[34]	SA1932

NUMERICAL
LISTINGS

GMC COACH — Camper Van

—	Motorhome	3178995	65448	65448
---	-----------	---------	-------	-------

GRANNING SUSPENSION (See Tuthill Technologies)

—	Caster Steering (2 Units Req'd.)	6608	—	66502
---	----------------------------------	------	---	-------

MOUNTING &
LENGTH BY PART

HOLIDAY RAMBLER — Motorhome (Class A)

2014-02	Models with Roadmaster Chassis RM8C, used on Ambassador - 4 Per Axle	01809927 557034 01809928 557035	557044 557044 — —	— — 557045 557045
2007-04	Models with Roadmaster Chassis R4R, used on Cayman, Neptune	—	557023	557012

MOUNTING &
LENGTH BY MOUNT

^[33] Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

^[34] 19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER

RECREATIONAL VEHICLES

OEM



HOLIDAY RAMBLER — Motorhome (Class A) (Cont.)

2003-00	Models with Roadmaster Chassis RM4C or used on Ambassador	01809924 01809923 01809925 01809926	557023 — 557031 —	— 557012 — 557032
	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Admiral, Endeavor Gas, Vacationer			
2003-99	Models with Ford E-Superduty/E450 Chassis with 6.8L Gas V10 used on Atlantis <i>For Towing and Hauling</i>	— — —	555031 — 557001	555032 555010 557007
	Models with Ford F53 Chassis with 6.8L Gas V10 used on Admiral, Endeavor Gas, Vacationer			
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Imperial, Navigator	—	555014	555015
2003-94	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Endeavor Diesel, Sceptor	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557001	557002
—	Models with Holiday Rambler Chassis used on Imperial			
	Front Drive Axle	90044794	66897	—
	Tag Axle	U0109007 U0109008	— —	— 34792
	Models with Spartan Mountain Master Chassis with Solid Front Axle used on Imperial, Navigator	—	557010 65431	65454

HOLIDAY RAMBLER — Travel Trailer

—	Trailer w/ 3500-5000 lb. Axles	18864 U01091	555002 555025	555002 555025
---	--------------------------------	-----------------	--------------------------------	--------------------------------

INTERNATIONAL — Motorhome Chassis For Class A

1975-70	1310 Motorhome Chassis w/ 137 in. & 159 in. W.B. and 10,000 GVW	—	—	34803
	1510 Motorhome Chassis w/ 178 in. W.B. and 12,000 GVW	—	—	34803

ISUZU — Motorhome

1995-87	NPR Chassis	—	66717	66618
---------	-------------	---	--------------	--------------

ITASCA (Winnebago) — Motorhome (Class C)

—	Models with VW Eurovan Chassis	—	37195	555041
---	--------------------------------	---	--------------	---------------



JOHN DEERE — Motorhome Chassis For Class A

1993-86	All	3638112 4036892	— 555011	— —
---------	-----	--------------------	--------------------	--------

MONACO — Motorhome (Class A)

2014-02	Models with Roadmaster Chassis RM8C, used on Diplomat, Dynasty - 4 Per Axle	01809927 557034 01809928 557035	557044 557044 — —	— —
2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	
2003-00	Models with Roadmaster Chassis RM4C or used on Knight	01809924 01809923 01809925 01809926	557023 — 557031 —	— —
	Models with Workhorse W22 Chassis with 8.1L Gas Monarch, LaPalma			
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Monarch, LaPalma	—	557001	557007
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. Above 29,600 to 46,000 GVW used on Dynasty, Signature, Executive	—	555014	555015
2003-90	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Diplomat, Windsor, Dynasty	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Monarch, LaPalma	—	557001	557002

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER



RECREATIONAL VEHICLES		OEM		
MONACO — Motorhome (Class A) (Cont.)				
—	Models with Spartan Mountain Master Chassis with Solid Front Axle Royal Coach Bus Conversion on Prevost Chassis Front	— 630136	65453 65472	65454
MOR-RYDE SUSPENSION				
—	Models with O.E. Number	U0109001 U0109004 U0109014 U0109016	555025 34792 555043 555043	555025 34792 555043 555043
OSHKOSH — Motorhome Chassis For Class A				
1995-89	V-Line 23000 - 26000 GVW Neway Suspension AR45	1745500	65412	65416
1994-86	M-Line w/ Leaf Spring Suspension with Front Axle Stabilizer Bar Forward of Axle with Front Axle Stabilizer Bar Rearward of Axle	— —	— 555011	— —
1993-85	Coaches w/ Neway Air Suspension	1583470	—	65416
PEAK CHASSIS — Motorhome Chassis For Class A				
2002-95	Alpine (Western RV) AS120 Suspension (Front) ARD200 Suspension (Rear)	B462093 B462092	557023 —	— 557012
PREVOST CAR — Motorhome Chassis For Class A				
—	LeMirage XL 40 ft., 45 ft. & H3-45 VIP Front Mirage	630136 010100905 12T113 9210100156 01013401 01013404	65472 65116 65116 65116 65116 65116	65407 65116 65116 65116 65116 65116
RIALTA (Winnebago) — Motorhome (Class C)				
2002-93	Rialta (VW Eurovan Chassis)	—	37195	555041
SAFARI — Motorhome (Class A)				
2007-04	Models with Roadmaster Chassis R4R, used on Simba RD	—	557023	557012
SAFARI MOTOR COACH (SMC) — Motorhome Chassis For Class A				
2000-96	Magnum Air B Series (Air-Ride) (4 Units Req'd Front & Rear)	B462092 —	66897 —	— 66897
2000-95	Magnum Blue Max M Series (Velvet Ride Torsion)	B462092 B462093	65432 —	— 65478
1999-93	Magnum Bluestreak Leaf Spring	B462092 B462093	65432 —	— 65478
SPARTAN — Motorhome Chassis For Class A				
2012-00	Summit (19000 - 22000 GVW)	B461725	65432	65433
2000-97	Mountainmaster / K2 (Verst) w/ Ind. Front Granning Suspension	B462151 B462385	— —	65454 65454
2000-95	Mountainmaster / K2 / Highlander (Verst) w/ I Beam Front Suspension	B461731 B461732 B462150 B462151	65431 — 65431 —	— 65454 — 65454
1995-91	Mountainmaster MC 2000	B461593 B461594	65431 —	— 65401

COMMERCIAL
VEHICLESRECREATIONAL
VEHICLESSCHOOL
BUSESBUSES &
COACHESTRUCKS, TRAILERS
& SUSPENSIONS

INTERCHANGES

NUMERICAL
LISTINGSMOUNTING &
LENGTH BY PARTMOUNTING &
LENGTH BY MOUNT

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER

RECREATIONAL VEHICLES		OEM		
SPARTAN — Motorhome Chassis For Class A (Cont.)				
—	1000 Motorhome Series	0251SS5 0252SS5 0277SS5 0278SS5	66666 — 66666 —	— 66667 — 66667
TOYOTA — Motorhome Chassis (Mini) For Class C				
1995-85	All	—	34953	34803
TRAVEL TRAILER — Retrofit Kit Shock				
—	Axles 1500 - 3500lb. (10 - 11¼" Static Length)	—	555002	555002
	Axles 2500 - 4600lb. (11¾ - 13¼" Static Length)	—	555003	555003
	Axles 2500 - 5000lb. (13¾ - 15½" Static Length)	—	555004	555004
	Axles 3500 - 7000lb. (15¾ - 16¾" Static Length)	—	555005	555005
TUTHILL TECHNOLOGIES				
—	101A-AR Rec Vehicle	1816601 1826601	— —	65401 65401
	102A-AR Rec Vehicle Drive Axle	1828601	—	65401
VIEW (Winnebago)				
2014	Ram Promaster Models	—	553007	66440
2015-07	Models with Freightliner or Dodge Sprinter Rear w/ Dual Wheels Rear w/ Single Wheel	— —	553003 —	66414 66415
2006-02	Models with Freightliner or Dodge Sprinter Rear w/ Dual Wheels Rear w/ Single Wheel	— —	553002 —	66417 66415
VOLKSWAGEN — Motorhome Chassis For Class B (Recreational Van Conversion)				
2001-00	Eurovan	—	NA	37196
1999-93	Eurovan	—	37195	37196
1991-80	Vanagon	—	34970	34971
WINNEBAGO — Motorhome (Class C)				
2002-93	Models with VW Eurovan Chassis	—	37195	555041
1991-86	LeSharo (Renault Chassis)			
WORKHORSE — Motorhome Chassis for Class A & C				
2007-05	Universal Floor Option (UFO)	661532	65432	—
—		—	—	65470
2007-05	W24 (24000 GVW)	W0006255	—	557032
2004-00	W20, W22 (20000 - 22000 GVW)	S1978	557031	—
2003-00		S1981	—	557032
2003-99	P30032 Standard (12,300 GVW)	—	557003	557004
	P30032 Widetrack (15000, 17000, 18000 GVW)	B461173 B461587	557003 —	— 557004
WORKHORSE — Motorhome Chassis for Class A & C — Steering Stabilizer				
			CYLINDER	COMPLETE KIT
2003-99	P30032 w/ OEM No. BE32645		555944 [Ⓜ]	—

Ⓜ 19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

PART NUMBER IN LIGHT FACE TYPE IS SUPERSEDING OR REPLACING THIS PART NUMBER