RECREATIONAL VEHICLES

		OEM		
ALKO/KOBER TRAILER AXLE				
—	4600, 5000 & 7000 lb. Axles	05200300 19176 19188	555001 555001 555025	555001 555001 555025
BLUEBIRD BUS — Motorhome (Class A)				
—	WanderLodge			
	Front	901968SP1	65430	—
	Front w/ Ridewell Air Suspension	1750785	65430	—
	Drive Axle	1750793	—	65474 74438
	Tag Axle	1722214	—	65421
CHEVROLET — Motorhome Chassis For Class A				
1999-95	P12 (P12) Motorhome Chassis	—	65443	65414
1999-92	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109014	U0109014	—	555043
1999-73	P30 (P32) Motorhome Chassis (Suggested for 12,300 GVW) — Exc. Monobeam Front Suspension	—	557003	557004
1999-73	P30 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater) — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P30 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004
1991-85	P30 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U01094	U0109004	—	34792
1985	P30 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1972-68	P30 (P32) Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
1972-68	P30 (P32) Motorhome Chassis w/ 157 in. W.B.	—	34817	—

CHEVROLET — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P30 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913[34]	—
1999-75	P30 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944	—

CHEVROLET — Motorhome Chassis For Class B (Recreational Van Conversion)

2005-96	3500 Series			
	Front	—	34741	—
	Rear w/ Dual Wheels	—	—	34756
	Load Assist Unit w/ Dual Rear Wheel	—	—	555009
	Rear w/ Single Wheel	—	—	34763
	Load Assist Unit w/ Single Rear Wheel	—	—	58612::
1995-92	G-30 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-30 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-30 Series — Exc. Chopped Van	—	555035	34803

CHEVROLET — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-30 Series w/o O.E. Steering Stabilizer	SC2915[33,34]	SA1932

CHEVROLET — Motorhome Chassis For Class C

2005-96	3500 Series Load Assist Unit w/ Motorhome Conversion	—	—	555009
2005-96	3500 Series w/ Motorhome Conversion	—	34741	34756
1996-93	30HD w/ Independent Front Suspension & Tilt Hood (P52) w/ Motorhome Conversion	—	557003	557004

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

:: This part number contains two per package.

38599_2016-17MonCV_04 RV.indd 12 6/7/17 1:37 PM

RECREATIONAL VEHICLES

		OEM		
CHEVROLET — Motorhome Chassis For Class C — Continued				
1996-93	**30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ Motorhome Conversion**	—	34912	557004
1995-92	**G-30 Series w/ Motorhome Conversion** — Exc. Chopped Van	—	555035	555036
1995-79	**G-30 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion**	—	555035	555036
1992-75	**G-30 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)**	90044769 90044770	—	66897 66897
1991-78	**G-30 Series w/ Motorhome Conversion** — Exc. Chopped Van	—	555035	555038
1978-75	**G-30 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion**	—	555035	—
1977-70	**G-30 Series w/ Motorhome Conversion** — Exc. Chopped Van	—	555035	34803

CHEVROLET — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-93	**30HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454**	SC2913[34]	—
1996-93	**30HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982**	555944	—
1993-70	**G-30 Series w/o O.E. Steering Stabilizer**	SC2915[33,34]	SA1932

COACHMEN — Motorhome (Class A)

—	**Models with Chevrolet Chassis - See Chevrolet Motorhome (Class A) Chassis**	—	557003	557004

DEXTER TRAILER AXLE

—	**4600, 5000 & 7000 lb. Axles**	05200300 19176 19188	555001 555001 555025	555001 555001 555025

DODGE — Motorhome Chassis For Class A

1981-77	**M6 Motorhome Chassis**	3638112 4036892	— 555011	555012 —
1981-73	**M & R-300, 400, 500 Motorhome Chassis**	3638112 3638631	— 555011	555012 —
1972-63	**M-300, M-375 & R-375 Motorhome Chassis**	2961043 3633744 3633745	— — 555013	555012 555012 —

DODGE — Motorhome Chassis For Class B (Recreational Van Conversion)

2003-95	**B-3500 Series** — Exc. w/ 9000 GVW	—	34831	555038
2003-95	**B-3500 Series w/ 9000 GVW**	—	555039	555038
1994	**B-350 Series** — Exc. w/ 9000 GVW	—	34831	555038
1994	**B-350 Series w/ 9000 GVW**	—	555039	555038
1993-70	**B-350 Series** — Exc. w/ 4000 lb. Front Axle	—	34831	555038
1993-70	**B-350 Series w/ 4000 lb. Front Axle**	—	555037	555038

DODGE — Motorhome Chassis For Class C

2003-95	**MB-3500 Motorhome Chassis** — Exc. w/ 9000 GVW	—	555037	555038
2003-95	**MB-3500 Motorhome Chassis w/ 9000 GVW**	—	555039	555038
1994	**MB-350 Motorhome Chassis** — Exc. w/ 9000 GVW	—	555037	555038
1994	**MB-350 Motorhome Chassis w/ 9000 GVW**	—	555039	555038
1993-70	**MB & BF-300 & 350 Motorhome Chassis** — Exc. w/ 4000 lb. Front Axle	—	555037	555038
1993-70	**MB & BF-300 & 350 Motorhome Chassis w/ 4000 lb. Front Axle**	—	555037	555038
1992-70	**MB & BF-300 & 350 Motorhome Chassis w/ Neway Tag Axle TA-3-CA (90044769, 90044770)**	90044769 90044770	—	66897 66897

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

38599_2016-17MonCV_04 RV.indd 13 6/7/17 1:37 PM

RECREATIONAL VEHICLES

DYNOMAX (COUNTRY COACH) — Motorhome Chassis For Class A

		OEM		
—	Dynomax Chassis (Allure & Intrique) 30000 - 32200 GVW w/ Beam Axle	89406 89414	65412 —	— 65401
—	Dynomax Chassis (Allure & Intrique) 30000 - 32200 GVW w/ Independent Front Axle	—	65433	65401

FORD — Motorhome Chassis For Class A

2007-99	Superduty Chassis Motorhome (F53) (Ref. 6.8L V10 Engine)	—	557001	557007
1997-93	Superduty Chassis Motorhome (F53 & F59) w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109016	—	—	555043
1997-88	Superduty Chassis Motorhome (F53 & F59) Over 30 ft. Motorhome (Ref. 7.5L (460) V8 Engine)	—	557001	557002
1976-73	M-400 & M-500 Motorhome Chassis	—	34828	—
1976-57	P-400 & 4000 Motorhome Chassis — Exc. H.D. Springs	—	34803	—
1976-57	P-400 & 4000 Motorhome Chassis w/ H.D. Springs	—	34828	—

FORD — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
2004-92	Superduty Chassis Motorhome (F53 & F59) w/ OEM No. E8T23E651A, F0TD3E651AA	555949[34]	—
1991-88	Superduty Chassis Motorhome (F53 & F59) w/o O.E. Steering Stabilizer	SC2912[33,34]	SA1930

FORD — Motorhome Chassis For Class B (Recreational Van Conversion)

2007-92	E-350 Series	—	555031	555032
1991-75	E-350 Series	—	555033	555034

FORD — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
2004-96	E-350 Series w/ OEM No. F2UA3E651AB, F7UZ3E651AA, F7UZ3E651AB, 6C2Z3E651B, 5C2Z3E651BA, 8C2Z3E651B	SC2955[34]	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer	SC2912[33,34]	SA1930

FORD — Motorhome Chassis For Class C

2007-97	E40, E400 Superduty Cutaway Chassis Load Assist Unit w/ Motorhome Conversion	—	—	555010
2004-97	E40, E400 Superduty Cutaway Chassis w/ Motorhome Conversion	—	555031	555032
2004-92	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555010
2004-92	E-350 Series w/ Motorhome Conversion	—	555031	555032
1991-75	E-350 Series Load Assist Unit w/ Motorhome Conversion	—	—	555020
1991-75	E-350 Series w/ Motorhome Conversion	—	555033	555034
1991-75	E-350 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	90044769 90044770	—	66897 66897

FORD — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
2007-97	E40, E400 Superduty Cutaway Chassis w/ OEM No. F2UA3E651AB, F7UZ3E651AA	SC2955[34]	—
2004-96	E-350 Series w/ OEM No. F2UA3E651AB, F7UZ3E651AA, F7UZ3E651AB, 6C2Z3E651B, 5C2Z3E651BA, 8C2Z3E651B	SC2955[34]	—
1996-80	E-350 Series w/o O.E. Steering Stabilizer	SC2912[33,34]	SA1930

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

38599_2016-17MonCV_04 RV.indd 14 6/7/17 1:37 PM

RECREATIONAL VEHICLES

		OEM		
FORETRAVEL — Motorhome (Class A)				
2001-95	U280, U300, U320 (4 Units Req'd Front & Rear)	B461868	66886	66633
FREIGHTLINER — Custom Chassis Motorhome for Class A				
2007-03	XC-Chassis & VC-Chassis (23000 GVW & Greater)			
	AS120 Suspension (Front)	1616737000	557011	—
	ADL200 Suspension (Rear)	1616736000	—	557012
2004-93	XC-Chassis & VC-Chassis (Up To 22000 GVW)	—	557011	557012
2002-01	XCS-Chassis w/ Air Suspension (Freightliner Rear Air)	1616020000	—	557030
		1616093000	557011	—
2002-00	XCS-Chassis 22000 GVW	1615755000	65453	—
		1616043000	65453	—
		—	—	66405
2002-93	XC-Chassis & VC-Chassis (23000 GVW & Greater)			
	AS90, AS120 Beam Suspension (Front) with ½ x 1¾ Upper Sleeve Mount	B462146M100	557011	—
		B462545M100	557011	—
	AS120, AS140 Beam Suspension (Front) with ¾ x 1¾ Upper Sleeve Mount	—	557023	—
	IFS114 Ind. Suspension (Front)	90045083	65433	—
		B462556M100	65433	—
	AD160, AD200 Suspension (Rear)	1614668000	—	557012
		B462147M100	—	557012
		B462546M100	—	557012
	FAS Airliner (Rear)	1616020000	—	557030
2000-97	Powerline (4 Units Req'd on Rear)	BE52581	—	557012
1999-96	MC Chassis	654918	66691	—
		P117099	—	66692
		P117146	66691	—
1998-92	M-Line w/ Leaf Spring Suspension			
	with Front Axle Stabilizer Bar Forward of Axle	—	—	555012
	with Front Axle Stabilizer Bar Rearward of Axle	—	555011	555012
FREIGHTLINER — Front-End Diesel Chassis (FRED)				
2008-06	All	1618094000	557039	—
		1618455000	557039	—
		47170000466	557039	—
		1700002726	557039	—
FREIGHTLINER — Motorhome Chassis For Class C				
—	FL 70 Series	—	65482	66957
GILLIG — Motorhome Chassis For Class A				
—	Motorhome w/ O.E. Number	1583470	—	65416
—	Neway Air Suspension	90044769	—	557012
		90044770	—	557012
GMC — Motorhome Chassis For Class A				
1999-92	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U0109014	U0109014	—	555043
1999-73	**P-3500 (P32) Motorhome Chassis (Suggested for 12,300 GVW)** — Exc. Monobeam Front Suspension	—	557003	557004
1999-73	**P-3500 (P32) Motorhome Chassis (Suggested for 14,300 GVW & Greater)** — Exc. Monobeam Front Suspension	—	557003	557004
1997-86	P-3500 (P62) Motorhome Chassis w/ Monobeam Front Susp.	—	34912	557004

38599_2016-17MonCV_04 RV.indd 15 6/7/17 1:37 PM

RECREATIONAL VEHICLES

GMC — Motorhome Chassis For Class A — Continued

		OEM		
1991-85	P-3500 (P32) Motorhome Chassis w/ MOR-RYDE Tag Axle w/ MOR-RYDE OEM U01094	U0109004	—	34792
1985	P-3500 (P42) Motorhome Chassis w/ Monobeam Front Susp.	—	555036	557004
1978-73	GMC Front Wheel Drive 24' & 26' Motorhome w/ Front Wheel Drive 4 Units Req'd on Rear	4975412	—	555046
1972-68	P-3500 Motorhome Chassis — Exc. 157 in. W.B.	—	34817	34803
1972-68	P-3500 Motorhome Chassis w/ 157 in. W.B.	—	34817	—

GMC — Motorhome Chassis For Class A Steering Stabilizer

		CYLINDER	COMPLETE KIT
1999-85	P-3500 (P42 / P62) Motorhome Chassis w/ Monobeam Front Susp. w/ OEM No. 22024068, 22046454	SC2913[34]	—
1999-75	P-3500 (P32) Motorhome Chassis w/ Independent Front Susp. w/ OEM No. 22011982, 4984838	555944	—

GMC — Motorhome Chassis For Class B (Recreational Van Conversion)

2005-96	3500 Series			
	Front	—	34741	—
	Rear w/ Dual Wheels	—	—	34756
	Load Assist Unit w/ Dual Rear Wheel	—	—	555009
	Rear w/ Single Wheel	—	—	34763
	Load Assist Unit w/ Single Rear Wheel	—	—	58612::
1995-92	G-3500 Series — Exc. Chopped Van	—	555035	555036
1991-78	G-3500 Series — Exc. Chopped Van	—	555035	555038
1977-70	G-3500 Series — Exc. Chopped Van	—	555035	34803

GMC — Motorhome Chassis For Class B (Recreational Van Conversion) Steering Stabilizer

		CYLINDER	COMPLETE KIT
1993-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915[33,34]	SA1932

GMC — Motorhome Chassis For Class C

2005-96	3500 Series Load Assist Unit w/ Motorhome Conversion	—	—	555009
2005-96	3500 Series w/ Motorhome Conversion	—	34741	34756
1996-93	3500HD Series w/ Independent Front Suspension & Tilt Hood (P52) w/ Motorhome Conversion	—	557003	557004
1996-93	3500HD Series w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ Motorhome Conversion	—	34912	66642
1995-92	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555036
1995-79	G-3500 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	555036
1992-75	G-3500 Series w/ Motorhome Conversion w/ Neway Tag Axle TA-3-CA (OEM 90044769, 90044770)	—	—	66636
1991-78	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	555038
1978-75	G-3500 Series Chopped Van w/ Dual Rear Wheels and Motorhome Conversion	—	555035	—
1977-70	G-3500 Series w/ Motorhome Conversion — Exc. Chopped Van	—	555035	34803

GMC — Motorhome Chassis For Class C Steering Stabilizer

		CYLINDER	COMPLETE KIT
1996-93	3500HD w/ Independent Front Suspension & Tilt Hood (P32 / P52) w/ OEM No. 22011982	555944	—
1996-93	3500HD w/ Straight Front Axle & Tilt Hood (P42 / P62) w/ OEM No. 220644062, 22046454	SC2913[34]	—
1991-70	G-3500 Series w/o O.E. Steering Stabilizer	SC2915[33,34]	SA1932

33 Cylinders are sold as Replacement Cylinders for Steering Stabilizer Kits.

34 SA-19XX Shock-Mate Boot Kit (See the preceding page of the Numerical for part numbers by color.) is available for use with our Steering Stabilizer Cylinders.

:: This part number contains two per package.

38599_2016-17MonCV_04 RV.indd 16 6/7/17 1:37 PM

RECREATIONAL VEHICLES

		OEM		
GMC COACH — Camper Van				
—	Motorhome	3178995	65448	65448
GRANNING SUSPENSION (See Tuthill Technologies)				
—	Caster Steering (2 Units Req'd.)	6608	—	66502
HOLIDAY RAMBLER — Motorhome (Class A)				
2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	557012
2007-04	Models with Roadmaster Chassis R4R, used on Neptune	—	557023	557012
2003-00	Models with Roadmaster Chassis RM4C or used on Ambassador	—	557023	557012
2003-00	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557031	557032
2003-99	Models with Ford E-Superduty/E450 Chassis with 6.8L Gas V10 used on Atlantis	—	555031	555032
	For Towing and Hauling	—	—	555010
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Admiral, Endeavor Gas, Vacationer	—	557001	557007
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Imperial, Navigator	—	555014	555015
2003-94	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Endeavor Diesel, Sceptor	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Admiral, Endeavor Gas, Vacationer	—	557001	557002
—	Models with Holiday Rambler Chassis used on Imperial			
	Front	90044794	66897	—
	Drive Axle	U0109007	—	555012
	Tag Axle	U0109008	—	34792
—	Models with Spartan Mountain Master Chassis with Solid Front Axle used on Imperial, Navigator	—	65431	65454
HOLIDAY RAMBLER — Travel Trailer				
—	Trailer w/ 3500-5000 lb. Axles	18864 U01091	555002 555025	555002 555025
INTERNATIONAL — Motorhome Chassis For Class A				
1975-70	1310 Motorhome Chassis w/ 137 in. & 159 in. W.B. and 10,000 GVW	—	—	34803
1975-70	1510 Motorhome Chassis w/ 178 in. W.B. and 12,000 GVW	—	—	34803
ISUZU — Motorhome				
1995-87	NPR Chassis	—	66717	66618
ITASCA (Winnebago) — Motorhome (Class C)				
—	Models with VW Eurovan Chassis	—	37195	555041
JOHN DEERE — Motorhome Chassis For Class A				
1993-86	All	3638112 4036892	— 555011	555012 —
MONACO — Motorhome (Class A)				
2007-04	Models with Roadmaster Chassis R4R, used on Cayman	—	557023	557012
2003-00	Models with Roadmaster Chassis RM4C or used on Knight	—	557023	557012
2003-00	Models with Workhorse W22 Chassis with 8.1L Gas V8 used on Monarch, LaPalma	—	557031	557032
2003-99	Models with Ford F53 Chassis with 6.8L Gas V10 used on Monarch, LaPalma	—	557001	557007

38599_2016-17MonCV_04 RV.indd 17 6/7/17 1:37 PM

RECREATIONAL VEHICLES

		OEM		
MONACO — Motorhome (Class A) — Continued				
2003-96	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. above 29,600 to 46,000 GVW used on Dynasty, Signature, Executive	—	555014	555015
2003-90	Models with Roadmaster Chassis Monocoque or Raised Rail w/ Air Susp. up to 29,500 GVW used on Diplomat, Windsor, Dynasty	—	555014	555015
1999-95	Models with Freightliner XC Chassis 22000 - 26000 GVW	—	557011	557012
1997-90	Models with Ford F53 Chassis with 7.5L/460CID Gas V8 used on Monarch, LaPalma	—	557001	557002
—	Models with Spartan Mountain Master Chassis with Solid Front Axle	—	65453	65454
—	Royal Coach Bus Conversion on Prevost Chassis			
	Front	630136	65472	—
MOR-RYDE SUSPENSION				
—	Models with O.E. Number	U0109001 U0109004 U0109014 U0109016	555025 34792 555043 555043	555025 34792 555043 555043
OSHKOSH — Motorhome Chassis For Class A				
1995-89	V-Line 23000 - 26000 GVW			
	Neway Suspension AR45	1745500	65412	65416
1994-86	M-Line w/ Leaf Spring Suspension			
	with Front Axle Stabilizer Bar Forward of Axle	—	—	555012
	with Front Axle Stabilizer Bar Rearward of Axle	—	555011	555012
1993-85	Coaches w/ Neway Air Suspension	1583470	—	65416
PEAK CHASSIS — Motorhome Chassis For Class A				
2002-95	Alpine (Western RV)			
	AS120 Suspension (Front)	B462093	557023	—
	ARD200 Suspension (Rear)	B462092	—	557012
PREVOST CAR — Motorhome Chassis For Class A				
—	LeMirage XL 40 ft., 45 ft. & H3-45 VIP			
	Front	630136	65472	65407
—	Mirage	010100905 12T113 9210100156 01013401 01013404	65116 65116 65116 65116 65116	65116 65116 65116 65116 65116
RIALTA (Winnebago) — Motorhome (Class C)				
2002-93	Rialta (VW Eurovan Chassis)	—	37195	555041
SAFARI — Motorhome (Class A)				
2007-04	Models with Roadmaster Chassis R4R, used on Simba RD	—	557023	557012
SAFARI MOTOR COACH (SMC) — Motorhome Chassis For Class A				
2000-96	Magnum Air B Series (Air-Ride) (4 Units Req'd Front & Rear)	B462092 —	66897 —	— 66897
2000-95	Magnum Blue Max M Series (Velvet Ride Torsion)	B462092 B462093	65432 —	— 65478
1999-93	Magnum Bluestreak Leaf Spring	B462092 B462093	65432 —	— 65478

38599_2016-17MonCV_04 RV.indd 18 6/7/17 1:37 PM

RECREATIONAL VEHICLES

		OEM		
SPARTAN — Motorhome Chassis For Class A				
2012-00	Summit (19000 - 22000 GVW)	B461725	65432	65433
2000-97	Mountainmaster / K2 (Verst) w/ Ind. Front Granning Suspension	B462151 B462385	— —	65454 65454
2000-95	Mountainmaster / K2 / Highlander (Verst) w/ I Beam Front Suspension	B461731 B461732 B462150 B462151	65431 — 65431 —	— 65454 — 65454
1995-91	Mountainmaster MC 2000	B461593 B461594	— —	— 65401
—	1000 Motorhome Series	0251SS5 0252SS5 0277SS5 0278SS5	66666 — 66666 —	— 66667 — 66667
TOYOTA — Motorhome Chassis (Mini) For Class C				
1995-85	All	—	34953	34803
TRAVEL TRAILER — Retrofit Kit Shock				
—	Axles 1500 - 3500lb. (10 - 11¼″ Static Length)	—	555002	555002
—	Axles 2500 - 4600lb. (11⅜ - 13¼″ Static Length)	—	555003	555003
—	Axles 2500 - 5000lb. (13⅜ - 15½″ Static Length)	—	555004	555004
—	Axles 4600 - 7000lb. (16⅞ - 20″ Static Length)	—	555006	555006
TUTHILL TECHNOLOGIES				
—	101A-AR Rec Vehicle	1816601 1826601	— —	65401 65401
—	102A-AR Rec Vehicle Drive Axle	1828601	—	65401
VIEW (Winnebago)				
2009-07	Models with Freightliner or Dodge Sprinter Rear w/ Dual Wheels Rear w/ Single Wheel	— —	— —	66417 66414
2006-02	Models with Freightliner or Dodge Sprinter Rear w/ Dual Wheels Rear w/ Single Wheel	— —	— —	66417 66415
VOLKSWAGEN — Motorhome Chassis For Class B (Recreational Van Conversion)				
2001-00	Eurovan	—	NA	37196
1999-93	Eurovan	—	37195	37196
1991-80	Vanagon	—	34970	34971
WINNEBAGO — Motorhome (Class C)				
2002-93	Models with VW Eurovan Chassis	—	37195	555041
1991-86	LeSharo (Renault Chassis) Left Units Right Units	— —	71975 71974	— —

38599_2016-17MonCV_04 RV.indd 19 6/7/17 1:37 PM

RECREATIONAL VEHICLES

WORKHORSE — Motorhome Chassis for Class A & C

		OEM		
2007-05	Universal Floor Option (UFO)	661532 —	65432 —	— 65470
2007-05	W24 (24000 GVW)	W0006255	—	557032
2003-00	W20, W22 (20000 - 22000 GVW)	S1978 S1981	557031 —	— 557032
2003-99	P30032 Standard (12,300 GVW)	—	557003	557004
2003-99	P30032 Widetrack (15000, 17000, 18000 GVW)	B461173 B461587	557003 —	— 557004

WORKHORSE — Motorhome Chassis for Class A & C Steering Stabilizer

		CYLINDER	COMPLETE KIT
2003-99	P30032 w/ OEM No. BE32645	555944	—

38599_2016-17MonCV_04 RV.indd 20 6/7/17 1:37 PM